



## PRIVACY DROP SHADES INSTALLATION INSTRUCTIONS

1. Center drop shades evenly on gazebo allowing 1 1/2" located on each side and the top
2. Once drop shade is positioned as you like it, locate top corner snap. Using a hammer, tap down on the snap lightly. This will leave a gentle indentation on the wood.
3. Using drill/screwdriver, install wood screw into the wood over the indentation.
4. Snap corner in place. move to opposite top corner making sure the drop shade is **pulled tight** and install wood screw and snap
5. Install the other screws and snaps between the top corners across the top, making sure the drop shade is level.
6. Position one bottom corner evenly and tightly against gazebo and install screw and snap in place. Install opposite bottom corner screw and snap evenly and tightly
7. Install the other screws and snaps between the top and bottom corners on both sides, making sure the drop shade remains even and tight.